

# Universal Free-Stand Filler Panel



Filler panels are installed between two-bayed panels to provide a flush surface to run conduit and mount components.

## FEATURES

Filler Panels are installed between two panels to provide a flush surface to run conduit and mount components.

## SPECIFICATIONS

| Catalog Number | Article Number | Height | Width | Depth | Material   | Finish        |
|----------------|----------------|--------|-------|-------|------------|---------------|
| AU72FP         | 38967          | 1524mm | 267mm | 21mm  | Mild Steel | Powder Coated |
| AU72FPG        | 39168          | 1524mm | 267mm | 21mm  | Mild Steel | Galvanized    |
| AU84FP         | 39167          | 1829mm | 267mm | 21mm  | Mild Steel | Powder Coated |
| AU84FPG        | 39171          | 1829mm | 267mm | 21mm  | Mild Steel | Galvanized    |
| AU90FP         | 60465          | 1981mm | 267mm | 21mm  | Mild Steel | Powder Coated |
| AU90FPG        | 60466          | 1981mm | 267mm | 21mm  | Mild Steel | Galvanized    |

## WARNING

nVent products shall be installed and used only as indicated in nVent's product instruction sheets and training materials. Instruction sheets are available at [www.nvent.com](http://www.nvent.com) and from your nVent customer service representative. Improper installation, misuse, misapplication or other failure to completely follow nVent's instructions and warnings may cause product malfunction, property damage, serious bodily injury and death and/or void your warranty.