

Mechanical Lightning Event Counter



FEATURES

Installs on downconductor to record number of lightning strikes

For use with nVent ERICO Ericore, conventional conductors or tape


SPECIFICATIONS

Table 1/2

Catalog Number	Enclosure Rating	Trip Threshold	Depth (D)	Height (H)	Width (W)	Temperature
LECIV	IP 67	2 kA 8/20 μ s	2.56"	4.33"	3.15"	-40 to 122 °F

Table 2/2

Catalog Number	Unit Weight	Complies With
LECIV	1.15 lb	EN IEC 62561-6



WARNING

nVent products shall be installed and used only as indicated in nVent's product instruction sheets and training materials. Instruction sheets are available at www.nvent.com and from your nVent customer service representative. Improper installation, misuse, misapplication or other failure to completely follow nVent's instructions and warnings may cause product malfunction, property damage, serious bodily injury and death and/or void your warranty.

North America

+1.800.753.9221
Option 1 – Customer Care
Option 2 – Technical
Support

Europe

Netherlands:
+31 800-0200135
France:
+33 800 901 793

Europe

Germany:
800 1890272
Other Countries:
+31 13 5835404

APAC

Shanghai:
+ 86 21 2412 1618/19
Sydney:
+61 2 9751 8500

